EM4806 De China de fábrica del medidor de humedad, Medidores de humedad para madera, El mini medidor de humedad EM4806 ofrece portabilidad fácil, un funcionamiento rápido y precisión. Fácil peración de un solo toque.
Se puede utilizar para medir el nivel de humedad en la madera aserrada (también de cartón, papel) y materiales endurecidos (yeso, hormigón y mortero). Se muestra el nivel de humedad en la recta material.
Además, EM4806 puede medir la temperatura ambiente.

Pliego de condiciones:

- Pantalla LCD Digtal
- Mini tamaño, portátil
- Fácil portabilidad, el funcionamiento y la precisión rápida
- Sonda de acero de 2 pines
- Indicador de batería baja
- La función de apagado automático
- Fácil de un solo toque peration
- ° C / ° F de la unidad

Pliego de condiciones:
Rango de madera: 6 ~ 42%
Rango de material de construcción: 0.2 ~ 2.0%
Temperatura ambiente: 0 ~ 40C / 32 ~ 99F
Batería: 1.5V, LR44 o equivalentes, 4 piezas
Tamaño de la unidad: 80 X 40 X 20 mm, peso neto: 50g, Accessries: Manual; Bolsa de transporte; anillo Clip

EM4806 de China medidor de humedad fábrica, medidores de humedad de la madera es su mejor elección.

3IN1
Wood/Building Material
MOISTURE METER
LCD
Measures environment temperature
Measures the moisture level of sawn timber
Measures hardened materials
MOISTURE METER
EM4806
ON
SET
NOTE:
Keep the probes clean
3IN1
Wood/Building Material
MOISTURE METER
INTRODUCTION
This instrument can be used to measure the moisture level in sawn timber (also paper, cardboard) and hardened materials (mortar, concrete and plaster). It displays the moisture level directly. In addition, it can also measure environment temperature. It is portable and very easy to use.
INSTRUCTION
Probe Cover
Probe
LCD Display
Button
NOTE
1. Keep the instrument dry.
2. Keep the probes clean.
3. Keep the instrument and battery out of reach of infant and child.
4. Some factors (such as material type and temperature) can affect moisture measurement result and may make it necessary to correct the displayed value. Don't use the instrument in the case of inspections or for reference purposes.
5. When the symbol " " appears, the batteries are low and should be replaced.
Ensure that battery polarity connections are correct when replacing batteries.
If you will not use the instrument for a long period, remove the batteries.
LCD