

## Specifications

1. Large-screen liquid crystal display ,visual clear mission.
2. Open the cell door ,according to positive and negative direction of the battery installed.
3. shows the current room temperature ,according to MAX-MIN key, correctly measuring the maximum ,minimum temperature values.When the MAX when refinancing a RESET button ,that is ,to remove the present value of maximum temperature.When the MIN, the RESET button to press once to clear the current value of the minimum temperature.
- 4 by °C-°F button to select the use of degrees .Celsius and degrees Fahrenheit.
5. use 0°C~50°C □B□ 32°F~122°F  
-40°C~70°C □A□ -58°F~158°F
6. Max outdoor temperature sensing distance:1.5M(A)
- 7 .In the normal temperature of 0°C~50°C environments.
8. Change the battery : Use the battery (1.5VDC) of AAA Size.
9. Package : 300PCS/CN ,45.5\*37.5\*51.5cm ,20.5KG