EM4806 Китай влагомер завод, Влагомеры для древесины, мини-измеритель влажности EM4806 имеет портативность, быстрая операция и точность. Легко одно касание Значение звукового.
Он может использоваться для измерения уровня влаги в пиломатериалов (также картон, бумага) и закаленных материалов (штукатурка, бетон и раствор). Он отображает уровень влажности в материальном сразу.
Кроме того, EM4806 может измерять температуру окружающей среды.

Спецификация:

● Digtal ЖК-дисплей
● Мини размер, портативный
● Легкая переносимость, быстрая работа и точность
● 2 контактный стали зонд
● Индикатор низкого заряда батареи
● Функция автоматического выключения питания
● Легко одно касание Значение звукового
● ° C / ° F обмен блока
Спецификация:
Диапазон древесины: 6 ~ 42%
Диапазон строительного материала: 0.2 ~ 2.0%
Температура окружающей среды: 0 ~ 40C / 32 ~ 99F
Батарея: 1.5V, LR44 или эквивалентные, 4 шт
Размер блока: 80 x 40 x 20 мм, Вес нетто: 50 г, Accessries: ручной; Carry мешок; Клип кольцо

EM4806 Китай Измеритель влажности завод, влагомеры для древесины ваш лучший выбор.

3IN1
Wood/Building Material
MOISTURE METER
LCD
MOISTURE METER
EM4806
ON
SET
Measures environment temperature
Measures the moisture level of sawn timber
Measures hardened materials
NOTE:
Keep the probes clean

3IN1
Wood/Building Material
MOISTURE METER
INTRODUCTION
This instrument can be used to measure the moisture level in sawn timber (also paper, cardboard) and hardened materials (mortar, concrete and plaster). It displays the moisture level directly. In addition, it can also measure environment temperature. It is portable and very easy to use.
INSTRUCTION
Probe Cover
Probe
LCD Display
Button
NOTE
1. Keep the instrument dry.
2. Keep the probes clean.
3. Keep the instrument and battery out of reach of infant and child.
4. Some factors (such as material type and temperature) can affect moisture measurement result and may make it necessary to correct the displayed value. Don't use the instrument in the case of inspections or for reference purposes.
5. When the symbol " " appears, the batteries are low and should be replaced.
Ensure that battery polarity connections are correct when replacing batteries.
If you will not use the instrument for a long period, remove the batteries.
LCD